

Vacuum pump V-i260SV



Flow rate	142 l/min
Vacuum level	99,997 %
Ultimate vacuum	15 micron
Power	3/4 KM
Intlet port	1/4" SAE
Oil capacity	580 ml
Dimensions	395 x 145 x 318 mm
Weight	16,6 kg

Pictures of some products may vary. Every effort has been made to ensure that the information contained in this catalog is correct. Due to constant technological development, we reserve the right to make changes without notice.

Vacuum pump V-i260SV

The vacuum pump is designed to work with refrigerants like HFC and HCFC (eg R410A, R407C). Dual stage vacuum pump is used in refrigeration and air conditioning.

The main features:

- dual-stage
- compact construction
- sight glass to control the oil level
- precision vacuum gauge
- the vacuum solenoid valve and preventing back flow of oil into the system