Product data sheet

COMPACT INFRARED THERMOMETER

Compact infrared thermometer with built-in laser pointer for fast and precise non-contact measurement.

•

Product features:

- Compact infrared thermometer
- Over range indication
- Large backlit LCD
- Brannan quality and accuracy ٠
- Data hold and power off function Full instructions and battery included •
- CE, WEEE and RoHS compliant • Supplied in individual box with protective pouch
- Complete with factory certificate of calibration •
- 3 point traceable calibration available on request (additional charge applies).

Product specifications:

-50 to 500°C&F	
<500ms	
12:1	
+/-2%, +/-2°C / 4°F	
Fixed at 0.95	
8 to 14µm	
0.1°C/°F	
0 to 50°C <95%RH (non-condensing)	
-20 to 70°C <80%RH	
Output <1mW, wavelength 630 to 670, class II	
1 x 9V (included)	
24mm x 25mm	
Net: 134mm x 89mm x 36mm	
Gross: 158mm x 100mm x 47mm	
Net: 130g (incl battery)	
Protective pouch: 37g	
Display box & instructions: 51g	
Gross: 218g	



Description	Range	Barcode	Product No
Compact infrared thermometer - low range	-50 to 500°C&F	5 011405 387035	38/703/0

NB: The meters' field of view, or distance to spot (D:S) indicates the distance required from the target spot. For example, where the field of view is 12:1, the thermometer should be 12cm from the target area. The diameter of the target must be at least 1cm.

DISTRIBUTOR:-BLUE HORIZON

Gopal Niwas, 135, Princess Street Mumbai-400002 INDIA Tel: +91 9820206611 sales.bluehorizon@gmail.com

