MC122 PRO/MC510 PRO/MC125 PRO

pH & ORP Controllers

With Milwaukee's MC Controllers you can monitor and control pH and/or ORP levels.

The Milwaukee Instruments MC Controllers have a user selectable set point and a visual "Power Activated" LED notification light. Power to the controller box is turned on when the reading is Above or Below the selected set point. These MC Controllers are ideal for CO₂ or ozone dosing. This could be controlled by a solenoid valve (MA955).

With each Milwaukee PRO controller, your aquarium will have the individual attention that it needs.

Each unit comes with 12 VDC adapter, mounting kit, probe and starter calibration solution for pH (factory calibrated for

Professional pH controller especially designed for use in aquariums and hydroponic systems.





Key features include:

- User selectable Hi/Low Set Point
- Manual 2 points calibration
- Visual LED alarm
- Supplied with 12 VDC adapter and mounting kit
- Power plug for CO, dosing
- Double junction pH electrode and/or platinum ORP electrode (BNC connector)

Specifications	MC122 PRO	MC510 PRO	MC125 PRO
Range	0.0 to 14.0 pH	±1000 mV (ORP)	0.00 to 14.00 pH; ±1000 mV (ORP)
Resolution	0.1 pH	1 mV (ORP)	0.1 pH; 1 mV (ORP)
Accuracy (@25°C)	±0.2 pH	±5 mV (ORP)	±0.2 pH; ±5 mV (ORP)
Set point pH	5.5 to 9.5 pH		4 to 8 pH
Set point ORP		0 to 600 mV	-200 to 600 mV
Alarm	active when measurement is higher	active when measurement is higher	active when measurement is higher
	or lower than selected set point	or lower than selected set point	or lower than selected set points
Output power socket	relay, 230V / 117V; 8A	relay, 230V / 117V; 8A	relay, 230V / 117V; 8A
Output	active when measurement is higher	active when measurement is higher	active when measurement is higher
	or lower than selected set point	or lower than selected set point	or lower than selected set points
pH Electrode	MA911B/2 (included)		MA911B/2 (included)
ORP Electrode		MA921B/2 (included)	MA921B/2 (included)
Environment	0 to 50°C / 32 to 122°F; max RH 95%	0 to 50°C / 32 to 122°F; max RH 95%	0 to 50°C / 32 to 122°F; max RH 95%
Power Supply	12 VDC power adapter (included)	12 VDC power adapter (included)	12 VDC power adapter (included)
Power Drivers	115VAC, 2A, 60Hz or 230VAC, 1A, 50Hz	115VAC, 2A, 60Hz or 230VAC, 1A, 50Hz	115VAC, 2A, 60Hz or 230VAC, 1A, 50Hz
Packaging dimensions	276 x 129 x 138 mm	276 x 129 x 138 mm	276 x 129 x 138 mm
Packaging weight	1.1 kg	0.9 kg	1.4 kg

Accessories













M10000B Flectrode rinse solution 20 ml sachet (25 pcs)

pH 4.01 buffer solution 20 mL M10004B sachet (25 pcs)

pH 7.01 buffer solution 20 mL M10007B sachet (25 pcs) M10010B pH 10.01 buffer solution 20 mL

sachet (25 pcs)

Electrode storage solution 20 mL MA9015 sachet (25 pcs)

MA9310 12 VDC Adapter, 220 V MA9311 12 VDC Adapter, 110 V MA955 Solenoid valve with 1.5 m cable

MA911B/2 Double junction, gel filled pH electrode

with 1 m cable

MA921B/2 ORP Electrode with BNC connector and 2 m cable

Ordering Information

MC122 PRO is supplied complete with MA9310 12 VDC adapter, MA911B/2 pH electrode, 20 mL pH4.01 sachet of calibration solution, 20 mL pH7.01 sachet of calibration solution, calibration screwdriver and instructions, in a carton box.

MC510 PRO is supplied complete with MA9310 12 VDC adapter, MA921B/2 ORP electrode and instructions, in a carton box.

MC125 PRO is supplied complete with MA9310 12 VDC adapter, power plug socket for ozone dosing, MA911B/2 pH electrode, MA921B/2 ORP electrode, 20 mL pH7.01 sachet of calibration solution, calibration screwdriver and instructions, in a carton box

DISTRIBUTOR:-

BLUE HORIZON

Gopal Niwas, 135, Princess Street Mumbai-400002 INDIA Tel: +91 9820206611 Email: sales.bluehorizon@gmail.com





